MX-D630

MINI-Compact System

MP3-CD/WMA-CD/CD-R/RW Playback

user manual

imagine the possibilities

Thank you for purchasing this Samsung product.
To receive more complete service,
please register your product at
www.samsung.com/register

SAMSUNG

Downloaded From Disc-Player.com Samsung Manuals

Safety Warnings

ENG

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER(OR BACK). NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

This symbol indicates “dangerous voltage” inside the product that presents a risk of electric shock or personal injury.	**CAUTION** : TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.	This symbol indicates important instructions accompanying the product.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN

WARNING

- To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

CAUTION

- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- The Mains plug is used as a disconnect device and shall stay readily operable at any time.
- This apparatus shall always be connected to a AC outlet with a protective grounding connection.
- To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
LUOKAN 1 LASER LAITE
KLASS 1 LASER APPARAT
PRODUCTO LÁSER CLASE 1

CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product.

Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION

- INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.

WHAT’S INCLUDED

Check for the supplied accessories below.

FM Antenna



User's Manual

Remote Control/Batteries(optional)

AM Antenna (Optional)

- Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance.
- An administration fee may be charged if either
  a. an engineer is called out at your request and there is no defect in the product
  (i.e. where you have failed to read this user manual)
  b. you bring the unit to a repair centre and there is no defect in the product
  (i.e. where you have failed to read this user manual).
- The amount of such administration charge will be advised to you before any work or home visit is carried out.

Downloaded From Disc-Player.com Samsung Manuals

Contents

Thank you for buying this SAMSUNG mini-compact system.

Please take time to read these instructions.
They will allow you to operate your system with ease and take full advantage of its features.

ENG

♦ SAFETY WARNINGS 2
♦ INSTALLING YOUR MINI-COMPACT SYSTEM
■ Front Panel View 4
■ Rear Panel View 5
■ Where to Install Your Mini-Compact System 5
■ Remote Control 6
■ Inserting Remote Control Batteries 6
■ Connecting your System to the Power Supply 7
■ Connecting the Speakers 7
■ Connecting to an External Source 7
■ Display Function 7
■ Connecting the FM Antenna 8
■ Connecting the AM Antenna (Optional) 8
■ Setting the Clock 8

♦ CD/MP3/WMA-CD-PLAYER
■ To replay the CD/MP3/WMA-CD 9
■ Selecting a Track 9
■ Searching for a Specific Music Passage on a CD 10
■ Repeating One or All Tracks on the Compact Discs 10
■ A-B Repeat Playback 10
■ Function to skip through 10 tracks at a time 10
■ Programming the Order of CD Playback 11
■ Checking or Changing Programmed CD Tracks 11

♦ USB
■ Playing USB 12
■ Selecting a Track from USB Device 12
■ Searching a Folder Quickly 12
■ To use high speed search 13
■ To repeat 13
■ To skip next 10 tracks 13
■ To delete a file 13

♦ TUNER
■ Searching for and Storing the Radio Stations 14
■ Selecting a Stored Station 14
■ Improving Radio Reception 14

♦ OTHER FUNCTIONS
■ Recording Function 15
■ Recording Speed 15
■ Timer Function 16
■ Cancelling the Timer 16
■ Mute Function 17
■ Selecting EQ Mode 17
■ GIGA SOUND Function 17
■ Setting the System to Switch off Automatically 18
■ Connecting Microphone 18

♦ RECOMMENDATIONS FOR USE
■ Safety Precautions 18
■ Cleaning Your Mini-Compact System 19
■ Precautions When Using Compact Discs 19
■ Before Contacting the After-Sales Service 19
■ Technical Specifications 20

Symbols Important Note

Downloaded From Disc-Player.com Samsung Manuals

Front Panel View



1. POWER button
2. MP3/CD button
3. EQ button
4. Search/Skip button
5. STOP/Tuning Mode button
6. USB REC button
7. USB jack
8. GIGA SOUND PRO button
9. Compact DISC Compartment
10. OPEN/CLOSE button
11. MIC jack
12. PLAY/PAUSE button
13. Search/Skip button
14. VOLUME
15. DELETE button
16. USB button
17. AUX button
18. TUNER button
19. Window Display

Downloaded From Disc-Player.com Samsung Manuals

Rear Panel View



1. Speaker Connector Terminals
2. ONLY FOR SERVICE (This jack is just for testing, please don't use it)
3. AM Antenna Connector Terminal(Optional)

☛ This product may not support the AM function depending on your region.

4. FM Antenna Connector Terminal
5. AUX IN Terminals

Where to Install Your Mini-Compact System

To take full advantage of your new mini-compact system, follow these installation instructions before connecting the unit.

- Install the system on a flat, stable surface.
- Never place this unit on carpeting.
- Never place this unit in an outdoor area.
- Maintain an open space of approximately 6 inches (15 cm) on the sides and rear of the system, for ventilation purposes.
- Make sure that you have enough room to open the compact disc compartment easily.
- Place the Speakers at a reasonable distance on either side of the system to ensure good stereo sound.
- Direct the Speakers towards the listening area.
- For optimum performance, make sure that both speakers are placed at an equal distance above the floor.

Downloaded From Disc-Player.com Samsung Manuals

Remote Control

ENG



1. POWER
2. CD REC SPEED
3. DISPLAY
4. TIMER ON/OFF
5. REPEAT
6. +10
7. MUTE
8. DELETE
9. Skip and Search *
10. Fast-Rewind
11. STOP
12. SOUND
13. ENTER
14. VOLUME -
15. MO/ST
16. TUNING/ALBUM ⌄
17. TUNING MODE
18. VOLUME +
19. TUNING/ALBUM ⌃
20. EQ
21. PLAY
22. Fast-Forward
23. PAUSE
24. MIC VOL +, -
25. REPEAT A-B
26. SLEEP
27. TIMER/CLOCK
28. DISC SKIP *
29. USB REC
30. FUNCTION

* This product is not used the **RDS PTY** and **RDS DISPLAY** function printed the ⏮, ⏭ button above.
* This product is not used the **DISC SKIP** function printed the **CD** button above.

Inserting Remote Control Batteries

Insert or replace remote control batteries when you:

- Purchase the mini-compact system
- Find that the remote control is no longer operating correctly

When replacing the batteries, use a new set of batteries and never mix alkaline and manganese batteries.



1 Place your thumb on the position marked ► on the battery compartment cover (rear of the remote control) and pull the cover in the direction of the arrow.

2 Insert two AAA, LR03 or equivalent batteries, taking care to respect the polarities:

- + on the battery on + in the battery compartment
- – on the battery on – in the battery compartment

3 Replace the cover by sliding it back until it clicks into position.

- If you will not be using the remote control for a long time, remove the batteries to prevent corrosion.
- The remote control can be used up to approximately 7 meters in a straight line. It can also be operated at a horizontal angle of up to 30° from the remote control sensor.

Downloaded From Disc-Player.com Samsung Manuals

Connecting your System to the Power Supply

Before plugging your system into a main socket, you must check the voltage.

1 Plug the main lead into an appropriate socket.

2 Press the **POWER (⏻/I)** button to switch your mini-compact system.





Connecting the Speakers

The Speakers connector terminals are located on the rear of the system.

- Left speaker (marked L)
- Right speaker (marked R)

1 To achieve the correct sound quality, insert those speaker connector cables to the speaker connector terminals of the system.



Connecting to an External Source

Connecting an External Analog Component

Example: Analog signal components such as a VCR, Camcorder, and TV.


AUX : Rear Panel
Audio Cable
If the external analog component has only one Audio Out, connect either left or right.
(not supplied)
AUX IN
AUDIO OUT

1 Connect **AUX IN** on the player to Audio Out on the external analog component.
- Be sure to match connector colors.

2 Press the **AUX** button to select the AUX input.

You can select AUX by pressing the **FUNCTION** button on the remote control.

DISPLAY function

You can view all functions available on the display, adjust the brightness of the display.

Each time you press the **DISPLAY** button on the remote control, the display mode will change as following:

- **The Demo function**
  All functions available on the system appear on the front panel display.
- **The Dimmer function**
  The Dimmer function is selected and the display darkens.
- **Display ON**
  The Display turns on.
- **Clock ON**
  The Clock you set is displayed.



Downloaded From Disc-Player.com Samsung Manuals

ENG

Connecting the FM Antenna

How to connect a COAXIAL TYPE antenna.

- Connect an antenna to the **FM** antenna terminal.
- Plug the connector on the **FM** antenna supplied into the coaxial socket marked **FM** on the rear of the system.
- Follow the instructions given on **Page 14** to tune into a radio station, and determine the best position for the antenna.



- If reception is poor, you may need to install an outdoor antenna.

To do so, connect an outdoor **FM** antenna to the **FM** socket on the rear of the system using a 75Ω coaxial cable (not supplied).



Connecting the AM Antenna (Optional)

Plug the connector on the AM antenna supplied into the AM Terminal on the rear of the system.



Setting the Clock

Your system is equipped with a clock which allows you to turn it on and off automatically.
You should set the clock:

- When you first purchase the mini-compact system
- After a power failure
- After unplugging the unit

For each step, you have a few seconds to set the required options. If you exceed this time, you must start again.

1 Switch the system on by pressing the **POWER (⏻ / I)** button.

2 Press the **TIMER/CLOCK** button twice.
Result: **CLOCK** is displayed.

3 Press the **ENTER (↵)** button.
Result: The hour flashes.

4

To..	Press the TUNING/ALBUM button
Increase the hours	∧
Decrease the hours	∨

5 When the correct hour is displayed, press the **ENTER (↵)** button.
Result: The minutes flash.

6

To..	Press the TUNING/ALBUM button
Increase the minutes	∧
Decrease the minutes	∨

7 When the correct time is displayed, press the **ENTER (↵)** button.
Result: The clock starts and is displayed.

- You can display the time, even when you are using another function, by pressing **TIMER/CLOCK** once.
- You can also use ⏮, ⏭ buttons on the main unit to instead of **TUNING/ALBUM** button ∧ or ∨ in step **4**, **6**.
- For more information of the TIMER function, please refer to the page 16.





Downloaded From Disc-Player.com Samsung Manuals

To replay the CD/MP3/WMA-CD

This is a player that enables the playback of audio CD, CD-R, CD-RW and MP3/WMA-CD.

You can play 12 cm or 8 cm compact disc without using an adapter.

- Never force the compact disc compartment when opening and closing the disc compartment.
- Never press down or place objects on the tray.
- Do not use CDs of irregular shapes like heart or octagon shapes. The performance of the player may be degraded.
- Always treat your compact discs with care; refer, if necessary, to the section entitled "**Precautions When Using Compact Discs**" on **page 19** .

1 Switch the system on by pressing the **POWER (⏻ / I)** button.

2 Press the **OPEN/CLOSE** button on the main unit.
Result: The compartment opens.

3 Place your disc in the compartment, with the label on the disc facingupwards.

4 Close the compartment by pressing the **OPEN/CLOSE** button again.
Result: Playback starts automatically.

- Your CD Player will take a few moments to scan through all the tracks recorded on a particular MP3/WMA-CD.
- The English name of the song may be indicated on the display only if directly downloaded from the PC or if the purchased MP3/ WMA-CD is sorted according to titles(directory). (Other languages besides English may not be indicated.)
- The English name of the track may not be indicated depending on the characteristics of the MP3/WMA-CD.

<CD/MP3/WMA-CD PlaybackDisplay>

Track Indicator —— 1 00:19 —— Playtime Indicator

5 Adjust the volume according to needs with the following procedures.
- Tuning the **VOLUME** knob.
- Press the **VOL +** or **—** button of the remote control.
The volume level can be adjust in 31 steps(VOLUME MIN, VOLUME 01- VOLUME 29, and VOLUME MAX).

6 Main Unit
To pause playback temporarily, press the ▶II button.
Press ▶II again to continue playing the disc.

Remote control
To pause playback temporarily, press the **PAUSE**(II) button.
Press **PLAY**(▶) button to continue playing the disc.

7. To stop playback, press the **STOP** (■) button.

- If there is not one CD inserted in the DISC compartment, it is indicated as "**NO DISC**".
- The quality of MP3/WMA-CD playback may vary depending on the condition of the disc containing the music files or the condition of the recorder with which the disc was created.
- If different types of files or unnecessary folders are on the same disc, you will have problems with playback.
- Keep the tray closed whenever you are not using it, to prevent dust from entering.
- You can load or unload compact disc when the radio, usb or auxiliary source function is selected, and when you press the **OPEN/CLOSE** button, all of the other functions will be changed to MP3/CD mode.
- A maximum of 999 tracks can be played per MP3-CD.



Selecting a Track

You can select the track you wish to listen to when a disc is playing.

To play the previous track
Press the ⏮ button within 3 seconds after the current track started playing.
Press the ⏮ button twice 4 seconds or later after the current track started playing.

To play the next track
Press the ⏭ button.

To play the current track
Press the ⏮ button 4 seconds or later after the current track started playing.

To play the track of your choice
Press the ⏮ or ⏭ button the appropriate number of times.

- You can also use the ⏮, ⏭ button on the remote control to select a track.



Downloaded From Disc-Player.com Samsung Manuals

ENG

Searching for a Specific Music Passage on a CD

When listening to a compact disc, you can quickly search for a specific music passage on a track.

To search through the tracks...	Press ...
Forwards	▶▶
Backwards	◀◀

You can also press and hold the ⏮, ⏭ button on the main unit to auto search through the tracks.



What is WMA?
- WMA means Windows Media Audio, the global standard for audio signal compression technology.

What is MP3?
- MP3 means MPEG1 Layer 3, the global standard for audio signal compression technology. It uses digital compression technology to compress original sound data by up to 12 times without sound quality degradation.

File Compatibility
- The unit will playback files created in MP3 format (Mpeg1.Layer3) with *.mp3 as their extension,and some WMA files with.WMA extension can't be playback.
- Playback will be impossible for the file of MP2 or 22KHz.

How many MP3 files can a CD-R or CD-RW disc record?
- The maximum capacity of one CD-R or CD-RW disc is 680MB.
- Normally, one MP3 file has a capacity of 4MB, therefore approximately 170 files can be recorded on a single disc.

Regarding the playback of CD-R/RW
- In the case of an original CD-R(Recordable) recorded in audio CD format, CD-RW(Rewritable) and editing by the user, playback is processed on the respective completed status. (The player may not be played back according to the characteristics of the CD or recorded status.)
- The CD-RW is comparably less reflexive than CD which causes more time delay to read.

Repeating One or All Tracks on the Compact Discs

You can repeat indefinitely:

- A specific track on a compact disc.
- All tracks on the compact disc selected.
- All discs loaded in the carrousel

1 Press the **REPEAT** button.
Each time you press the **REPEAT** button, the repeat mode will change as following:

MP3: R OFF → R TRK → R DIR → R DISC → R RAN

CD: R OFF → R TRK → R DISC → R RAN

2 When you wish to stop the Repeat function, press the **REPEAT** button until **R OFF** is displayed.
- **R OFF:** Cancels Repeat Playback.
- **R TRK:** Repeatedly plays the selected track.
- **R DIR:** Repeatedly plays all tracks in the selected folder.
- **R DISC:** Repeatedly plays the entire disc.
- **R RAN:** Plays tracks in random order.

A-B Repeat Playback

You can repeatedly play back a designated section of a CD.

1 Press the **REPEAT A-B** button at the beginning of desired part.
- **R A-** will be displayed.

2 Press the **REPEAT A-B** button at the ending of desired part.
- **R A-B** will be displayed.

3 To cancel REPEAT A-B function, press **REPEAT A-B** button again.
'R OFF' will be displayed.

REPEAT A-B function is available within a track.



Function to skip through 10 tracks at a time

Press the +10 button briefly while playing back a CD and MP3/WMA-CD . The track 10 after the current one will then be played back.

Example: If you want to select track 43 during playback of track 5, press the **+10** button four times, and then press the ⏮ button two times .

5 → 15 → 25 → 35 → 45 → 44 → 43

+10 +10 +10 +10 ⏮ ⏮



Downloaded From Disc-Player.com Samsung Manuals

Programming the Order of CD Playback
(This function is not available during playback of an MP3/WMA-CD.)

You can decide:
- The order of the track desired to listen
- The track not desired to listen

➢
- You can program up to 24 tracks.
- You must stop the compact disc player before selecting the tracks.

1 If the CD function is selected, stop the player by pressing the **STOP** (■) button.

2 Press the **ENTER (⏎)** button.

Result: The following indications are displayed:

P01 -- --

(01 = Program no., -- -- = Track no. on the disc)

3 Select the required track by pressing the ⏮, ⏭ button:
- Press the ⏮ button to move back through the tracks.
- Press the ⏭ button to move forward through the tracks.

4 Press the **ENTER (⏎)** button to confirm your selection.

Result: The selection is stored and P02 -- -- is displayed.

5 To select other tracks, repeat Steps **3** to **4**.

6 Press **PLAY** (▶) to listen to the track selection in the order programmed.

7 When press the **STOP** (■) button one time , compact disc player is stopped, and press the **STOP** (■) button again to cancel the selection.

➢ If you open the compartment or turn off the power or change function, the selection is cancelled.



Checking or Changing Programmed CD Tracks

You can check or change your selection of tracks at any time.

1 Press the **STOP** (■) button once if you have started listening to the selection.

2 Press the **ENTER (⏎)** button.

Result: The following indications are displayed:

C01 02

(CH = Check, 01=Program No, -- -- = Track No on the disc)

➢ If you have already programmed 24 tracks, **CH** is displayed instead of **PROG** when you press the **ENTER (⏎)** button.

3 Press the **ENTER (⏎)** button once or more times until the track to be changed is displayed.

4 Press ⏮ or ⏭ button to select a different track.

5 Press the **ENTER (⏎)** button to confirm your change.

6 Press the **PLAY** (▶) button to start listening to the selection.

Result: The first track selected is played.



Downloaded From Disc-Player.com Samsung Manuals

Playing USB

ENG

You can play MP3/WMA files by connecting to various external USB storage devices such as USB flash memory or HDD(Hard Disc drives).

1 Connect the external USB storage device to the USB jack on your player.

2 Select USB by pressing the **USB** button on the main unit.

You can select **USB** by pressing the **FUNCTION** on the remote control.

- The first track of the first directory plays automatically.

➢ **To stop playing**
Press the **STOP** (■) button to stop playing.

➢ **To remove the USB device**
If you press the **STOP** (■) button once again, you can remove the USB device safely.







☛ Do not connect a USB charging device to the USB connection port on the player, because it may cause damage to the product.

Please be aware of the following before using USB.

- Some external USB storage devices may not be compatible with this player.
- With external HDD, FAT format can be played.
- With USB 2.0 HDD, connect to a separate power source.
  If it's not connected to a separate power source, it may not work.
- If memory of an external USB storage device is segmented into several parts, MP3 files of only the first hard disk drive can be played.
- DRM applied files are not played.
  Digital Rights Management (DRM): Technology and service that protect the profit and rights of copyright owners by disallowing unauthorised use of digital contents.
- Even if the file name ends with .mp3, the file does not play if actual file format is MPEG layer 1 or 2.
- Do not use a USB hub as it will not be recognized.
- Up to 16 letters of MP3/WMA file name will be shown.

Delay

- When selecting USB function, file reading (READ-IN) may take several minutes.
- When playing a USB device, there may be a delay then advancing to the next track, especially with HDD.
  The operation time of external USB storage devices will vary; even when they are of the same capacity.
- If the external USB storage device supports only USB VER1.1 and the access speed is slow,the file may not property.

Selecting a Track from USB Device

You can select an MP3 file during the play.

Before you begin!
- Connect the external USB storage device to your player.
- Select the USB by pressing the USB button on the main unit.

➢ If you want to move the next/previous(track), press the ⏮,⏭ button shortly.

- It moves the next/previous file within the directory.
- If you press the ⏮,⏭ button more times than the number of the files in the directory, it will move over to the next directory.



Searching a Folder Quickly

1 Press the **TUNING/ALBUM** button on the remote control to move to the previous/next folder.

2 When the searching is done, you will see the previous/next folder name. The track will start playing.



Downloaded From Disc-Player.com Samsung Manuals

Playing USB(continue)

ENG

To use high speed search

Before you begin! ◆ Connect the external USB storage device to your player.
◆ Select USB by pressing the USB button on the main unit.

You can search the desired section quickly during the play.

➢ Press the ◀◀ , ▶▶ button.
◆ Whenever you press the button, you can search backward or forward quickly.

☛ When you use the high speed search function, there is no sound.



To repeat

Before you begin! ◆ Connect the external USB storage device to your player.
◆ Select USB by pressing the USB button on the main unit.

1 Press the **REPEAT** button.
Each time you press the **REPEAT** button, the repeat mode will change as following:
R OFF → R TRK → R DIR → R ALL → R RAN

2 When you wish to stop the Repeat function, press the **REPEAT** button until **R OFF** is displayed.
- **R OFF:** Cancels Repeat Playback.
- **R TRK:** Repeatedly plays the selected track.
- **R DIR:** Repeatedly plays all tracks in the selected folder.
- **R ALL:** Repeatedly plays all tracks.
- **R RAN:** Plays tracks in random order.



To skip next 10 tracks

Before you begin! ◆ Connect the external USB storage device to your player.
◆ Select USB by pressing the USB button on the main unit.

➢ Press the **+10** button on the remote control shortly during the play.
Example: If you want to select 43rd track while 15th track is playing, press the **+10** button 3 times, and then press the ⏮ button 2 times.

15 → 25 → 35 → 45 → 44 → 43
(+10) (+10) (+10) (⏮) (⏮)



To delete a file

You can delete a file on your USB device.

Before you begin! ◆ Connect the external USB storage device to your player.
◆ Select USB by pressing the USB button on the main unit.

1. Play a file you want to delete.
2. Press the **DELETE** button.
3. Press ⏮,⏭ on the remote control to select YES.
4. Press the **ENTER** button on the remote control.
The selected file will be deleted.

☛ The NTFS file system is not supported.



Downloaded From Disc-Player.com Samsung Manuals

ENG

Searching for and Storing the Radio Stations

You can store up to: 15 FM stations, 15 AM stations.

1 Switch the system on by pressing the **POWER (⏻ / I)** button.

2 Select TUNER by pressing the **TUNER** button on the main unit.
You can select TUNER by pressing the FUNCTION button on the remote control.

3 Select FM or AM by pressing the **TUNER** button again in the TUNER mode on the main unit.

4

To search for a station	Press TUNING MODE button
Preset	Once or more times until **PRESET** is displayed. You can search the stored frequencies in the Preset mode.
Manually	Once or more times until **MANUAL** is displayed. You can search the frequencies one by one in the Manual mode.

5 Select the station to be stored by:

- Pressing **TUNING/ALBUM** ∧ or ∨ on the remote control.
- To scroll through the frequencies faster when searching manually, press and hold the **TUNING/ALBUM** ∧ or ∨ on the remote control.
- The automatic search procedure may stop on a frequency that does not correspond to a radio station. If this happens, use the manual search mode.

6 Adjust the volume by:

- Turning the **VOLUME** knob on the front panel

or

- Pressing the **VOL +** or **–** buttons on the remote control

7 Select the FM stereo or mono mode by pressing **MO/ST**.
- In the AM Radio, the MO/ST button does not work.

8 If you do not want to store the radio station found, revert to Step **4** and search for another station.
Otherwise:

a Press the **ENTER (↵)** button.

b Press the **ENTER (↵)** button to store the radio station.

9 To store any other radio frequencies required, repeat Steps **3** to **7**.

➢ **In Tuner mode**
- In the Manual mode, you can use ⏮ or ⏭ button on the main unit to manual search a radio station.
- During the Auto Searching mode, press **STOP(■)** button on the main unit to stop auto searching.
- In the Preset mode, you can use ⏮ or ⏭ button on the main unit to search a stored radio station.



Selecting a Stored Station

You can listen to a stored radio station as following:

1 Switch the system on by pressing the **POWER (⏻ / I)** button.

2 Select TUNER by pressing the **TUNER** button on the main unit.
You can select TUNER by pressing the **FUNCTION** button on the remote control.

3 Select FM or AM by pressing **TUNER** button again in the TUNER mode on the main unit.

4 Press the **TUNING MODE** button on the remote control until "**PRESET**" is displayed.

5 Press ⏮ or ⏭ to select the desired station.
or
Select the desired station by pressing the **TUNING/ALBUM** ∧ or ∨ button on the remote control.
Result: The desired station is now received.



Improving Radio Reception

You can improve the quality of radio reception by:
- Rotating the FM antenna
- Testing the positions of the FM antenna before fixing them permanently
- If reception from a specific FM radio station is poor, press the **MO/ST** button to switch from stereo mode to mono.
The quality of the sound will be improved.
- In the AM Radio, the **MO/ST** button does not work.



Downloaded From Disc-Player.com Samsung Manuals

Recording Function

You can record sound of the CD, the Radio Broadcasting or sound from the external source into the USB storage device.

1 Switch the system on by pressing the **POWER (⏻ / I)** button.

2 Connect the external USB storage device you want to record to the USB ( ) on your player.

3 Play a Disc, adjust the Radio frequency or connect the external source to your player.

CD (See page 9)

- Press the **MP3/CD** on the main unit to select the CD function.
- Press the **OPEN/CLOSE** button to open the Compact Disc compartment.
- Insert a CD and press the **OPEN/CLOSE** button to close the Compact Disc compartment.
- Use the CD selection (⏮ or ⏭) buttons to select the desired song.

Tuner (See page 14)

- Select TUNER by pressing the **TUNER** button on the main unit.
- Adjust the Radio frequency you want to record.

External Source (See page 7)

- Connect an External Component/MP3 player to your player.
- Press the **AUX** button to select <AUX> input.
- Play a song from the external device.

4 Press the **USB REC** button to start recording.

CD

- "TRACK RECORDING" is displayed and CD recording starts.
- Press and hold the **USB REC** button to start recording the all tracks of Disc.
  "RECORDING" is displayed.
- If you record the MP3 CD, the file is copied into the USB device totally.
  "COPY XX"→"COPY END" is displayed. When the recording is done, "STOP" will be displayed.
- If there is the same file name, "FILE EXISTED" is displayed, and the function is canceled.

Tuner /External Source

- RECORDING is displayed.

5 To stop recording, press the **STOP** (■) button and then automatically create and save as the MP3 file.

6 To remove the USB device safely, press the **STOP** (■) button once again.

- After the recording, a directory named "RECORDING"(CD), "CD COPY"(MP3 CD), "TUNER RECORDING" or "AUX RECORDING" will be created in your device.

- Do not disconnect the USB or the AC Cord during the recording as this may cause file damage.
- If you disconnected USB device during the recording, the main unit will be power off and you may not delete the recorded file, In this case, please connect the USB device to the PC and backup the USB data on the PC first and then format the USB device.
- When the USB memory is not enough, it will be displayed "NOT ENOUGH MEMORY".
- The recording works if the USB device or the HDD is formatted in the FAT file system. (The NTFS file system is not supported.)
- When you use CD high speed search function, the CD recording can't work.
- Sometimes, the recording time may be longer with some USB devices. (See page 12)
- In the program mode, you can't use the CD recording function. (See page 11)
- When the CD recording, the EQ and GIGA SOUND functions can not work and automatically change to OFF.
- When the CD recording, the REPEAT function can not work and automatically changes to OFF.
- If you use the MIC function during the CD recording, the voice from the microphone will be recorded.
- You can not record the radio when searching or no available frequencies in the Tuner mode.

- Note that setting the input level too loud when recording music from an external device through the AUX and USB channel may introduce noise into the recording. In that case, lower the external device's volume level.





Recording Speed

Each time you press the CD REC SPEED button on the remote control, the recording speed will change as following:

RECORDSPD x 1→RECORDSPD x 4

- While the Tuner or External Source is recording, the recording speed does not supported.
- When you select **RECORDSPD x 4**, the audio sound will not be output.



Downloaded From Disc-Player.com Samsung Manuals

Timer Function

ENG

The timer enables you to switch the system on or off at specific times automatically.
Example: You wish to wake up to music every morning.

- ◆ Before setting the timer, check that the current time is correct.
- ◆ For each step, you have a few seconds to set the required options. If you exceed this time, you must start again.

If you no longer want the system to be switched on or off automatically, you must cancel the timer by pressing the **TIMER ON/OFF** button.

1 Switch the system on by pressing the **POWER (⏻/I)** button.

2 Press the **TIMER/CLOCK** button until **TIME** is displayed.

3 Press the **ENTER (⏎)** button.
Result: **ON** is displayed for a few seconds, you can set the timer switch-on time.

4 Set the timer switch-on time.
a Press the **TUNING/ALBUM** ∧ or ∨ button to set the hours.
b Press the **ENTER (⏎)** button.
Result: The minutes flash.
c Press the **TUNING/ALBUM** ∧ or ∨ button to set the minutes.
d Press the **ENTER (⏎)** button.
Result: **OFF** is displayed for a few seconds, you can now set the timer switch-off time.

5 Set the timer switch-off time.
a Press the **TUNING/ALBUM** ∧ or ∨ button to set the hours.
b Press the **ENTER (⏎)** button.
Result: The minutes flash.
c Press the **TUNING/ALBUM** ∧ or ∨ button to set the minutes.
d Press the **ENTER (⏎)** button.
Result: **VOL XX** is displayed, where **XX** corresponds to the volume already set.

6 Press the **TUNING/ALBUM** ∧ or ∨ button to adjust the volume level and press the **ENTER (⏎)** button.
Result: The source to be selected is displayed.

7 Press the **TUNING/ALBUM** ∧ or ∨ button to select the desired source to be played when the system switches on.

If you select...	You must also...
FM/AM (radio)	**a** Press the **ENTER (⏎)** button.
	b Select a preset station by pressing the **TUNING/ALBUM** ∧ or ∨ button.
CD/MP3 (compact disc)	Load one compact disc.
USB.....	Connect the USB device.

8 Press the **ENTER (⏎)** button.
Result: **CHK REC** (Do you want to record?) is displayed.

9 Press the **ENTER (⏎)** button.
Result: **REC N** is displayed, you can press the **TUNING/ALBUM** ∧ or ∨ button to select the **REC Y** or **REC N**, and then press **ENTER** button.
1). If you select the REC N, it will cancel tuner timing recording even if you have already set the tuner timing recording.
2). If you select the REC Y, you can set the tuner timing recording.
a. Press the **ENTER (⏎)** button.
Result: **ON** is displayed for a few seconds, you can set the tuner timing recording switch-on time.
b. Press the **ENTER (⏎)** button.
Result: **OFF** is displayed for a few seconds, you can set the tuner timing recording switch-off time.

- ◆ The maximal tuner timing recording time is 5 hours.
- ◆ If the timer switch on and off times are identical, the word **ERROR** is displayed.
- ◆ You may use ⏮, ⏭ buttons on the main unit to instead of the **TUNING/ALBUM** ∧ or ∨ button to adjust in step **5** to 9.
- ◆ If the switch-on or -off time is the same as the timing recording time, only the switch-on or -off time is effective, and the timing recording time is not applied.



Cancelling the Timer

After having set the timer, it will start automatically as shown by the TIMER indication on the display. If you no longer wish to use the timer, you must cancel it.

To...	Press the TIMER ON/OFF button....
Cancel the timer	Once.
	Result: ◔ is no longer displayed.
Restart the timer	Twice.
	Result: ◔ is displayed again.



Downloaded From Disc-Player.com Samsung Manuals

Mute Function

You can turn the sound off temporarily on your system.
Example: You wish to answer a telephone call.

1 Press the **MUTE** button.

2 To switch the sound back on , press the **MUTE** button again or the **VOLUME** buttons.



Selecting EQ Mode

Your mini-compact system is equipped with a preset equalizer that allows you to choose the most appropriate balance between treble and bass frequencies, according to the type of music you are listening to.

1 Press the **EQ** button until the required option is selected.

Select...	To obtain a...
OFF	Normal balance (linear)
RANCHA	Banlace suitable for Rancha Music.
SAMBA	Banlace suitable for Samba Music.
CUMBIA	Banlace suitable for Cumbia Music.
HABANA	Banlace suitable for Habana Music.
BOOM BA	Banlace suitable for Boom Ba Music.
REGGAE	Balance suitable for Reggae Music
PARTY	Balance suitable for Party Music
POP	Balance suitable for Pop Music
HIPHOP	Balance suitable for HipHop Music
ROCK	Balance suitable for Rock Music
JAZZ	Balance suitable for Jazz Music
CLASS	Balance suitable for Class Music
FLAT	Balance suitable for Flat Music
STA+EQ	Banlace suitable for Stadium Music.
DYN+S	Banlace suitable for Dynamic spot Music.
MP3+	Banlace suitable for MP3 Enhan Music.
VIR+S	Banlace suitable for Virtual Music.
U1 B 0	Banlace suitable for User 1 mode Music.
U2 B 0	Banlace suitable for User 2 mode Music.
U3 B 0	Banlace suitable for User 3 mode Music.

2. Set the BASS (left numeric), MIDDLE (middle numeric), TREBLE (right numeric) level.

Press the **ENTER** button when you select the U1 B 0 / U2 B 0 /U3 B 0.
Result: The BASS level(left numeric) flash.
Press the **TUNING/ALBUM** ∧ or ∨ button to select from -06 to 06.
Press the **ENTER** button.
Result: The MIDDLE level(middle numeric) flash.
Press the **TUNING/ALBUM** ∧ or ∨ button to select from -06 to 06.
Press the **ENTER** button.
Result: The TREBLE level(right numeric) flash.
Press the **TUNING/ALBUM** ∧ or ∨ button to select from -06 to 06.
Press the **ENTER** button.
Result: setting is completed.

- When CD Recording, the EQ function can't work and the EQ automatically switches to "OFF" mode.
- If no buttons is pressed within 8 seconds, your settings will automatically be cancelled and the previous settings will be saved.



GIGA SOUND function

Your mini-compact system is equipped with the function of GIGA SOUND mode .
The function of GIGA SOUND mode amplifies bass and improves high key or bass twice as much for you to appreciate powerful real sound.

1 Press the **GIGA SOUND PRO** button on the main unit or the **SOUND** button on the remote control.
Each time press this button, the sound will switch as following:

OFF → GIGA SOUND → GIGA LOUDNESS

2 To cancel this function, press the **GIGA SOUND PRO** button until the "**OFF**" is displayed.





Downloaded From Disc-Player.com Samsung Manuals

ENG

Setting the System to Switch off Automatically

While listening to music, you can set the system to switch off automatically.
Example: You wish to go to sleep while listening to music.

1 Press **SLEEP**.
Result: playback starts and the following indications are displayed:
90MIN

2 Press **SLEEP** once or more times to indicate how long the system should continue playing before it switches off:
90MIN → 60MIN→ 45MIN → 30MIN → 15MIN → SLPOFF

➢ At any time, you can:

- Check the remaining time by pressing **SLEEP**.
- Change the remaining time by repeating steps **1** and **2**.

3 To cancel SLEEP function, press **SLEEP** once or more times until **SLPOFF** is display.



Connecting Microphone

You can also insert microphone to sing along with your favorite CDs.

Plug a microphone with a 3.5ø MIC jack into the MIC terminal.

- Press the **MIC +,-** button on the remote control to adjust the Microphone Volume.
- If you use the Microphone, GIGA SOUND will automatically turn off. Even if you remove the microphone, it will not turn on.
- This Microphone function is available only when using the CD or USB function.



Safety Precautions

The following diagrams illustrate the precautions to be taken when using or moving your mini-compact system.



Ambient operating conditions:
Ambient temperature 5°C-35°C
Humidity 10-75%



Do not expose the unit to direct sun radiation or other heat sources. This could lead to overheating and malfunction of the unit.



Do not place potted plants or vases on top of the unit. Moisture entering the unit could lead to dangerous electric shock and can cause equipment damage. In such events immediately disconnect the main plug from the socket.



During thunderstorms, disconnect the main plug from the socket. Main voltage peaks due to lightning could damage the unit.



Remove the batteries from the remote control, if not used for any extended period.
Leaking batteries can cause serious damage to the remote control.



When using headphones, take care not to listen at excessive volumes. Extended use of headphones at high volumes will lead to hearing damage.



Do not place heavy items on the main lead. Main cable damage can lead to damage of the equipment (fire hazard) and can cause electric shock.



Do not disassemble, repair, or modify this unit on your own, as it may cause malfunction or a risk of electric shock.

Downloaded From Disc-Player.com Samsung Manuals

Cleaning Your Mini-Compact System

To obtain the best possible results from your mini-compact system, you must clean the following elements regularly:

- The outer casing
- The compact disc player
- The cassette players (heads, rollers and drive capstans)

Always unplug the system from the wall outlet:

- Before cleaning it
- If you are not going to be using it for a long time

Outer Casing

Clean the outer casing regularly using a soft cloth and a light detergent. Do not use abrasive powders, liquids or aerosol cleaners. Never let any liquids get into the system.

Compact Disc Player

1 Before playing a compact disc, clean it with a special CD cleaning agent. Do not use the same cleaning agents as for vinyl LP records. Carefully wipe the disc from the centre outward.

2 Regularly clean the player with a special cleaning disc (available from your local dealer).

- If you will not be using the remote control for a long time, remove the batteries to prevent corrosion.
- Although your system is very hard-wearing, it should not be used in an excessively dusty environment or subjected to shocks or extreme heat (close to heating appliances or in direct sunlight, etc.).
- If the unit emits an unpleasant odor when in use, unplug it from the main supply and contact the after-sales service.

Precautions When Using Compact Discs

- Handle your compact discs with care. Always hold them by the edges to avoid leaving fingerprints on the shiny surface.
- When you have finished playing a compac disc, always put it back in its case.
- Do not fix paper or adhesive tape to the discs and do not write on the label.
- Clean them with a special-purpose cloth.
- Store your compact discs in a clean place, out of direct sunlight, where they will not be exposed to high temperatures.
- Always use compact discs marked .



Before Contacting the After-Sales Service

ENG

It always takes a little time to become familiar with a new appliance. If you have any of the problems listed below, try the solutions given. They may save you the time and inconvenience of an unnecessary service call.

If the above guidelines do not allow you to solve the problem, take a note of:

- The model and serial numbers, normally printed on the rear of the system
- Your warranty details
- A clear description of the problem

Then contact your local dealer or SAMSUNG after-sales service.

	Problem	Checks/Explanation
GENERAL	The system does not work	• *The main lead is not correctly plugged into a wall socket or the wall socket is not switched on.* • *The remote control batteries need replacing or the polarity has not been respected.* • *The **POWER** button has not been pressed.*
	There is no sound	• *The volume has been completely turned down.* • *The correct function (TUNER, MP3/CD, USB, AUX) has not been selected.* • *You have connected a set of earphones.* • *The loudspeaker wires have been disconnected.* • *The **MUTE** button has been pressed.*
	The Timer does not work	• *The timer has been stopped by pressing **TIMER ON/OFF**.*
	In case it does not work, even the action is taken as above.	• *Press the **STOP** button for 5 seconds in "NO DISC" mode, then it is returned the original position (RESET)*
CD/MP3/CD	The compact disc player does not start playing	• *The CD function has not been selected.* • *The disc has been inserted face down or is either dirty or scratched.* • *The laser sensor is dirty or dusty.* • *The system has not been installed on a flat, horizontal surface.* • *Condensation has formed in the player; leave the system in a warm, airy room for at least one hour.*
RADIO	Reception is poor or no radio stations are received at all	• *The **TUNER** function has not been selected.* • *The radio frequency has not been correctly selected.* • *The aerial has been disconnected or is not facing the right way. Turn it until you find the best orientation.* • *You are in a building that blocks radio waves; you must use an outside aerial.*

Downloaded From Disc-Player.com Samsung Manuals

Technical Specifications

ENG

SAMSUNG strives to improve its products at all times. Both the design specifications and these user instructions are thus subject to change without notice.

RADIO	
FM	
Signal/noise ratio	55 dB
Usable sensitivity	12 dB
Total harmonic distortion	0.6 %
AM (Optional)	
Signal/noise ratio	40 dB
Usable sensitivity	58 dB
Total harmonic distortion	1.5 %
COMPACT DISC PLAYER	
Capacity	1 disc
Frequency range	20 Hz - 20 KHz (± 1 dB)
Signal/noise ratio	80 dB (at 1kHz, with filter, 2V)
Distortion	0.3 % (at 1 KHz)
Channel separation	50 dB
Disc sizes	Diameter: 120 or 80 mm. Thickness: 1.2 mm
AMPLIFIER	
Output power	
MX-D630- 130 Watts (10% THD)	
Front Speaker	65 W/CH (4 Ω / 100 Hz)
MX-D630- 160 Watts (MAX. THD)	
Front Speaker	80 W/CH (4 Ω / 100 Hz)
Channel separation	65 dB
Signal/noise ratio	80 dB
GENERAL	
Dimensions	223 (W) x 306 (H) x 282 (D) mm
Weight	2.5 Kg

*: Nominal specification

- Samsung Electronics Co., Ltd reserves the right to change the specifications without notice.
- Weight and dimensions are approximate.
- Design and specifications are subject to change without prior notice.
- For information on the power supply and power consumption, refer to the label attached to the product.

Downloaded From Disc-Player.com Samsung Manuals

Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care centre.

ENG

Area	Contact Center ☎	Web Site
▪ North America		
Canada	1-800-SAMSUNG (726-7864)	www.samsung.com
Mexico	01-800-SAMSUNG (726-7864)	www.samsung.com
U.S.A	1-800-SAMSUNG (726-7864)	www.samsung.com
▪ Latin America		
Argentine	0800-333-3733	www.samsung.com
Brazil	0800-124-421 / 4004-0000	www.samsung.com
Chile	800-SAMSUNG (726-7864)	www.samsung.com
Colombia	01-8000112112	www.samsung.com
Costa Rica	0-800-507-7267	www.samsung.com
Dominica	1-800-751-2676	www.samsung.com
Ecuador	1-800-10-7267	www.samsung.com
El Salvador	800-6225	www.samsung.com
Guatemala	1-800-299-0013	www.samsung.com
Honduras	800-7919267	www.samsung.com
Jamaica	1-800-234-7267	www.samsung.com
Nicaragua	00-1800-5077267	www.samsung.com
Panama	800-7267	www.samsung.com
Peru	0-800-777-08	www.samsung.com
Puerto Rico	1-800-682-3180	www.samsung.com
Trinidad & Tobago	1-800-SAMSUNG (726-7864)	www.samsung.com
Venezuela	0-800-100-5303	www.samsung.com
▪ Europe		
Albania	42 27 5755	-
Austria	0810 - SAMSUNG (7267864, € 0.07/min)	www.samsung.com
Belgium	02-201-24-18	www.samsung.com/be (Dutch) www.samsung.com/be_fr (French)
Bosnia	05 133 1999	-
Bulgaria	07001 33 11	www.samsung.com
Croatia	062 SAMSUNG (062 726 7864)	www.samsung.com
Czech	800-SAMSUNG (800-726786) Samsung Zrt., česká organizační složka, Oasis Florenc, Sokolovská394/17, 180 00, Praha 8	www.samsung.com
Denmark	70 70 19 70	www.samsung.com
Finland	030 - 6227 515	www.samsung.com
France	01 48 63 00 00	www.samsung.com
Germany	01805 - SAMSUNG (726-7864 € 0,14/Min)	www.samsung.com
Hungary	06-80-SAMSUNG (726-7864)	www.samsung.com
Italia	800-SAMSUNG (726-7864)	www.samsung.com
Kosovo	+381 0113216899	-
Luxemburg	261 03 710	www.samsung.com
Macedonia	023 207 777	-
Montenegro	020 405 888	-
Netherlands	0900-SAMSUNG (0900-7267864) (€ 0,10/Min)	www.samsung.com
Norway	815-56 480	www.samsung.com
Poland	0 801 1SAMSUNG (172678) / 022-607-93-33	www.samsung.com
Portugal	80820-SAMSUNG (726-7864)	www.samsung.com
Rumania	1. 08010 SAMSUNG (72678) - doar din rețeaua Romtelecom, tarif local 2. 021.206.01.10 - din orice rețea, tarif normal	www.samsung.com

Area	Contact Center ☎	Web Site
Serbia	0700 Samsung (0700 726 7864)	www.samsung.com
Slovakia	0800-SAMSUNG (726-7864)	www.samsung.com
Spain	902-1-SAMSUNG (902 172 678)	www.samsung.com
Sweden	0771 726 7864 (SAMSUNG)	www.samsung.com
Switzerland	0848-SAMSUNG (7267864, CHF 0.08/min)	www.samsung.com/ch www.samsung.com/ch_fr/(French)
U.K	0330 SAMSUNG (7267864)	www.samsung.com
Eire	0818 717100	www.samsung.com
Lithuania	8-800-77777	www.samsung.com
Latvia	8000-7267	www.samsung.com
Estonia	800-7267	www.samsung.com
▪ CIS		
Russia	8-800-555-55-55	www.samsung.com
Georgia	8-800-555-555	-
Armenia	0-800-05-555	-
Azerbaijan	088-55-55-555	-
Kazakhstan	8-10-800-500-55-500 (GSM: 7799)	www.samsung.com
Uzbekistan	8-10-800-500-55-500	www.samsung.com
Kyrgyzstan	00-800-500-55-500	www.samsung.com
Tadjikistan	8-10-800-500-55-500	www.samsung.com
Ukraine	0-800-502-000	www.samsung.ua www.samsung.com/ua_ru
Belarus	810-800-500-55-500	-
Moldova	00-800-500-55-500	-
▪ Asia Pacific		
Australia	1300 362 603	www.samsung.com
New Zealand	0800 SAMSUNG (0800 726 786)	www.samsung.com
China	400-810-5858 / 010-6475 1880	www.samsung.com
Hong Kong	(852) 3698 4698	www.samsung.com/hk www.samsung.com/hk_en/
India	3030 8282 / 1800 110011 / 1800 3000 8282 / 1800 266 8282	www.samsung.com
Indonesia	0800-112-8888 / 021-5699-7777	www.samsung.com
Japan	0120-327-527	www.samsung.com
Malaysia	1800-88-9999	www.samsung.com
Philippines	1-800-10-SAMSUNG(726-7864) / 1-800-3-SAMSUNG(726-7864) / 1-800-8-SAMSUNG(726-7864) / 02-5805777	www.samsung.com
Singapore	1800-SAMSUNG (726-7864)	www.samsung.com
Thailand	1800-29-3232 / 02-689-3232	www.samsung.com
Taiwan	0800-329-999	www.samsung.com
Vietnam	1 800 588 889	www.samsung.com
▪ Middle East		
Bahrain	8000-4726	www.samsung.com
Egypt	08000-726786	www.samsung.com
Jordan	800-22273	www.samsung.com
Morocco	080 100 2255	www.samsung.com
Oman	800-SAMSUNG (726-7864)	www.samsung.com
Saudi Arabia	9200-21230	www.samsung.com
Turkey	444 77 11	www.samsung.com
U.A.E	800-SAMSUNG (726-7864)	www.samsung.com
▪ Africa		
Nigeria	0800-SAMSUNG (726-7864)	www.samsung.com
South Africa	0860-SAMSUNG (726-7864)	www.samsung.com

Downloaded From Disc-Player.com Samsung Manuals

AH68-02320B

Downloaded From Disc-Player.com Samsung Manuals